

Gerätetypen / Recorder Models / Type d'appareil

XY-Schreiber / Recorder / Enregistreur LY18/PL, LY1500, LY1600

Ersatzteil-Nr. Geräte-Hersteller

Manufacturer Part-Number

Réf. Constructeur

Farben

Colours

Couleurs

DIA-Nummer

DIA-Part-Number


Référence DIA

80116023, LY/HP01	grün	green	vert	F51082 -04X-05
80116024, LY/HP02	rot	red	rouge	F51082 -02X-05
80116025, LY/HP05	schwarz	black	noir	F51082 -01X-05

Halter LY/HP vom Hersteller

Contact manufacturer for holder LY/HP

Pour les supports LY/HP contacter le constructeur



Gerätetypen / Recorder Models / Type d'appareil

Kassettenschreiber Serie / Cassette Recorder Series / Enregistreur à cassette Série

2000, 2001, 2005, 7000, 7005, 7105

Type L2020, L2021, L2025, L2040, L2041, L2045, L2060, L2061, L7020, L7025, L7040, L7045, L7060, L7065, L7125, L7145, L7165, L7720, L7740

Ersatzteil-Nr. Geräte-Hersteller

Manufacturer Part-Number

Réf. Constructeur

Farben

Colours


Couleurs

DIA-Nummer

DIA-Part-Number

Référence DIA

L0/01, L0/1, L2001/1	grün	green	vert	F51171 -04X-01
L0/02, L0/2, L2001/2	rot	red	rouge	F51172 -02X-01
L0/03, L0/3, L2001/3	blau	blue	bleu	F51173 -03X-01
L0/04, L0/4, L2001/4	braun	brown	marron	F51174 -05X-01
L0/05, L0/5, L2001/5	schwarz	black	noir	F51175 -01X-01
L0/06, L0/6, L2001/6	violett	violet	violet	F51176 -06X-01



F51252 / x = 44,0

Gerätetypen / Recorder Models / Type d'appareil

XY-Schreiber / Recorder / Enregistreur LY1400, LY1500, LY1600, LY1900PL

Ersatzteil-Nr. Geräte-Hersteller

Manufacturer Part-Number

Réf. Constructeur

Farben

Colours

Couleurs


DIA-Nummer

DIA-Part-Number

Référence DIA

	lieferbar	available	disponibles	F51252 -**X-05
	01 - 11	01 - 11	01 - 11	

F51323 / x = 39,2 F51327 / x = 107,4
 F51324 / x = 56,1 F51328 / x = 124,5
 F51325 / x = 73,2
 F51326 / x = 90,3




Gerätetypen / Recorder Models / Type d'appareil

Flachsreiber / Flat bed recorder / Table traçante LM23, LM24, LS25, LS45, LS51, LS65, L601, L651, L652, L6010, L6012, L6510, L6512, L6514, L6520, L6522

Ersatzteil-Nr. Geräte-Hersteller

Manufacturer Part-Number Réf. Constructeur	Farben	Colours	Couleurs	DIA-Nummer DIA-Part-Number Référence DIA
L0/210, L0/21	grün	green	vert	F51323 -04X-01
L0/220, L0/22	rot	red	rouge	F51324 -02X-01
L0/230, L0/23	blau	blue	bleu	F51325 -03X-01
L0/240, L0/24	braun	brown	marron	F51326 -05X-01
L0/250, L0/25	schwarz	black	noir	F51327 -01X-01
L0/260, L0/26	violett	violet	violet	F51328 -06X-01




F51339 / x = 19,2
 F51583 / x = 33,8

Gerätetypen / Recorder Models / Type d'appareil

LY700, LY722Z, LY800, LY1700, LY1722T, LY1800, LY1822Z, LY17100, LY17200, LY18100, LY1822ZZ

Ersatzteil-Nr. Geräte-Hersteller

Manufacturer Part-Number Réf. Constructeur	Farben	Colours	Couleurs	DIA-Nummer DIA-Part-Number Référence DIA
L0/4010, L0/411	grün	green	vert	F51339 -04X-01
L0/4020, L0/422	rot	red	rouge	F51583 -02X-01




F51584 / x = 34,3
 F51585 / x = 48,2

Gerätetypen / Recorder Models / Type d'appareil

LM300, L600, L650, L6012-1, L6012-2, L6522-1, L6522-2

Ersatzteil-Nr. Geräte-Hersteller

Manufacturer Part-Number Réf. Constructeur	Farben	Colours	Couleurs	DIA-Nummer DIA-Part-Number Référence DIA
LM300/1	grün	green	vert	F51584 -04X-01
LM300/2	rot	red	rouge	F51585 -02X-01



F51847 / x = 32,5

Gerätetypen / Recorder Models / Type d'appareil

LY171, 172, 181, LY1500, 1600, LY17100, 17100, LY181000, L2005+E, 2006, 2007, L2025, L2045+E, L2046, L2065+E, L2100, 2101, 2200, L2200, 4000, 4100, L7005L, L7605

Ersatzteil-Nr. Geräte-Hersteller

Manufacturer Part-Number Réf. Constructeur	Farben	Colours	Couleurs	DIA-Nummer DIA-Part-Number Référence DIA
L2005/52	schwarz	black	noir	F51847 -01X-05
L2005/22	rot	red	rouge	F51847 -02X-05
L2005/32	blau	blue	bleu	F51847 -03X-05
L2005/12	grün	green	vert	F51847 -04X-05
L2005/42	braun	brown	marron	F51847 -05X-05
L2005/62	violett	violet	violet	F51847 -06X-05