



F51005 / x = 57,0

Gerätetype / Recorder Model / Type d'appareil

..77, 157, 197, 225, 257, 281, 283, 297, 323, 340, 357, 397, 402, 457, 552S, 554, 555, 556, 557, 580B, 597, 700, 720, 781, Serie / Serie / Série 1400

Ersatzteil-Nr. Manufacturer Part-Number Réf. Constructeur	Farben	Colours	Couleurs	DIA-Nummer DIA-Part-Number Référence DIA
067809, 094018, 211-0671, 0497-0092	schwarz	black	noir	F51005-01F-05
211-0670, 0497-0090, 132884	rot	red	rouge	F51005-02F-05
211-067X, 0497-0091, 132885	blau	blue	bleu	F51005-03F-05
211-0672, 0497-0089, 132886	grün	green	vert	F51005-04F-05
132887	violett	violet	violet	F51005-06F-05
067808	2 Stück	2 pens each of black	2 stylos	
	schwarz	black	noir	
	je 1 Stück	1 each of	1 stylo	
	rot	red	rouge	
	blau	blue	bleu	
	grün	green	vert	
	violett	violet	violet	



F51015 / x = 54,4

Gerätetype / Recorder Model / Type d'appareil

..21, ..25, 125, 221, 225, 325, 421, 521, 621

Ersatzteil-Nr. Manufacturer Part-Number Réf. Constructeur	Farben	Colours	Couleurs	DIA-Nummer DIA-Part-Number Référence DIA
067811	schwarz	black	noir	F51015-01F-05
067810	2 Stück	2 pens each of black	2 stylos	
	schwarz	black	noir	
	je 1 Stück	1 each of	1 stylo	
	rot	red	rouge	
	blau	blue	bleu	
	grün	green	vert	
	violett	violet	violet	



F51040 / x = 35,8

Gerätetype / Recorder Model / Type d'appareil

159, 1655, 169, QPD 33

Ersatzteil-Nr. Geräte-Hersteller

Manufacturer Part-Number

Réf. Constructeur

Farben

Colours


Couleurs

DIA-Nummer

DIA-Part-Number

Référence DIA

053764	rot	red	rouge	F51040-02S-05
053869	schwarz	black	noir	F51040-01S-05
053870	blau	blue	bleu	F51040-03S-05
053871	violett	violet	violet	F51040-06S-05
053872	grün	green	vert	F51040-04S-05
053765				W20114



W20114

Gerätetype / Recorder Model / Type d'appareil

59S, 56M, 56D nur untere Feder / only for lower pen / seulement pour stylos position basse

Ersatzteil-Nr. Geräte-Hersteller

Manufacturer Part-Number

Réf. Constructeur

Farben

Colours


Couleurs

DIA-Nummer


DIA-Part-Number

Référence DIA

053764	rot	red	rouge	F51040-02S-05
053869	schwarz	black	noir	F51040-01S-05
053870	blau	blue	bleu	F51040-03S-05
053871	violett	violet	violet	F51040-06S-05
053872	grün	green	vert	F51040-04S-05
070106				W20170



W20170



F51094 / x = 28,3

Gerätetype / Recorder Model / Type d'appareil

IR 237, 137, X 37

Ersatzteil-Nr. Geräte-Hersteller

Manufacturer Part-Number

Réf. Constructeur

Farben

Colours

Couleurs

DIA-Nummer

DIA-Part-Number


Référence DIA

				F51094-**Z-05
	lieferbar	available	disponibles	
	01 - 06	01 - 06	01 - 06	


Gerätetype / Recorder Model / Type d'appareil

561D

Ersatzteil-Nr. Geräte-Hersteller Manufacturer Part-Number Réf. Constructeur	Farben	Colours	Couleurs	DIA-Nummer DIA-Part-Number Référence DIA
023-1254	grün	green	vert	F51104G -04S-05
023-1255	rot	red	rouge	F51142B -02S-05



F51104G / x = 19,02




F51142B / x = 6,4

Gerätetype / Recorder Model / Type d'appareil

200, 220, 561H, 561L, 561M, 571, 572, 575, P100, R50, R100A

Ersatzteil-Nr. Geräte-Hersteller Manufacturer Part-Number Réf. Constructeur	Farben	Colours	Couleurs	DIA-Nummer DIA-Part-Number Référence DIA
CP-285010, 040-1740, 023-0567	schwarz	black	noir	F51142B -01S-05
CP-285020, 040-1743, 023-0569	grün	green	vert	F51142B -04S-05
CP-285030, 040-1742, 023-0566	blau	blue	bleu	F51142B -03S-05
CP-285040, 040-1741, 023-0568	rot	red	rouge	F51142B -02S-05



F51104G / x = 19,02

Gerätetype / Recorder Model / Type d'appareil

Ersatzteil-Nr. Geräte-Hersteller Manufacturer Part-Number Réf. Constructeur	Farben	Colours	Couleurs	DIA-Nummer DIA-Part-Number Référence DIA
023-1253	rot	red	rouge	F51153B -02S-05